










MFM can be configured and Programmed On site for the following :
PT Primary, PT Secondary, CT Primary, CT Secondary (5A) and System
Type 3 phase 3W or 4W or single phase system. The front panel has Four
keys using which the user can scroll through different screens and
configure the product.




Sr. No.	Para.	Description
		Technical Specification.
		User Interface.
		Home Page Screen Description
		Parameter setting mode.
1	PRSS	Enter password.
2	CT ₁ PRSS	Change the password.
3	CT ₁ PRSS	Set new password.
4	3W	Network selection 3P-3W and 3P-4W.
5	CT ₂	Select CT secondary ratio.
6	CT ₁ P	Select CT primary ratio.
7	PT ₂	Select PT secondary ratio.
8	PT ₁ P	Select PT primary ratio.
9	r-Hr	Run Hour Selection
10	Id	Slave ID
11	BRUD	Baud Rate
12	PrL	Sets the parity check.
13	rSt Fct	Factory Reset
14	rSt EnrL	Reset Energy
15	ErSt PRSS	Energy Reset Password
16	rSt μH	Reset Active Energy
17	rSt μURH	Reset Apparent Energy
18	rSt URRH	Reset Reactive Energy
19	rSt H-n	Reset Run Hour
20	rSt nR-	Reset MAX
		Error Messages
		Wiring Diagram

Housing	: Front Cover: Polycarbonate Plastic Back Cover: ABS Plastic
Dimensions	: Frontal : 96 X 96mm, Depth : 61mm : 91 X 91mm
Panel Cutout	: Flush panel mounting with Fasteners
Mounting	: IP65 Front
Protection	: Terminal connectors.
Connections	: ≤ 2.5sq mm terminal only with U-type lugs.
Display	: Customized Display
Data storage	: Non-volatile flash memory
Operating temp.	: 0°C to 60°C (non-condensing)
Operating humidity	: 20% to 85% (non-condensing)
Storage temp	: -25°C to 60°C (non-condensing)
Supply Voltage	: 240 Vac ±20 % , 50/60Hz Standard.
Wiring Input	: 3ø-4W, 3ø-3W system.
Measuring Range	
Input Rated Voltage	: 11 to 500 V AC (L-N) : 19 to 866 V AC (L-L)
Input Rated Current	: Nominal 5AAC
CT Primary	: 5 A to 10 kA
CT Secondary	: 5 A
PT Primary	: 100 V to 500 kV
PT Secondary	: 100 V to 500 V AC (L-L)
Electrical Connection	: 3ø-4W, 3ø-3W, 2ø-3W, 1ø-2W.
Resolution	
Energy	: 0.01k, 0.1k, 0.01M, .01M, 1M (Depending upon CT ratio and PT ratio)
Current / Voltage / Power	: Auto Resolution
Power Factor	: 0.001
Measuring Parameter Accuracy	
Voltage, Current & AVG	: ± 0.5% of Full Scale
Frequency	: ± 0.1Hz ± 1 digit
Run Hours	: ± 1%
Active Power	: 1%
Reactive Power	: 1%
Apparent Power	: 1%
Active Energy Class	: 1
Reactive Energy Class	: 1
Apparent Energy Class	: 1
Power Factor	: ±0.5% of Unity
Display Scrolling	: Automatic or Manual (Programmable)
Power Consumption	: 1.5VA Max
Frequency	: 45-65 Hz
Run Hours	: 0 to 99999.9 Hrs
Burden	: 0.5VA @5A per phase



No.	Description	
1	Electrical parameters like AC Voltage, AC Current, Frequency and Power Factor will be seen as Per screen no and auto or manual mode. Kindly refer Home Page Description.	
2		
3		
4	k	Kilo
5	V	Unit Volts
6	L-N	Line to Neutral of corresponding phase
7	L-L	Line to Line of corresponding phase
8	A	Ampere
9	AVG	Average value of corresponding parameter
10	PF	Power Factor
11	Hz	Frequency
12	M	Mega
13	Wh	Active Energy
14	MAX	Max Value of corresponding parameter
15	VARh	Reactive Energy
16	VAR	Reactive Power
17	Total	Total Value
18	VAh	Apparent Energy
19	VA	Apparent Power
20	IM	Import Energy
21	EX	Export Energy
22		Next key : In Manual Mode: To scroll for Next Screen. In Program Mode: To scroll to Next Parameter. Note: Kindly refer 'Home Page Screen Description' for further details.
23		Down key: In Normal Mode (Auto/Manual): To scroll through screens one by one in a particular page. In Program Mode: To decrease Parameter value.
24		Up key : In Normal Mode (Auto/Manual): To scroll through screens one by one in a particular page In Program Mode: To increase Parameter value.
25	 A/M	Exit key : In Normal Mode: Press this key for 6 seconds to toggle between Automatic/Manual Mode. In Program Mode: To save the changed Parameter and exit to Normal mode. Note: Kindly refer 'Home Page Screen Description' for further details.

When power is On, entire display part will be On for 5 sec, MFM will be displayed for 3 sec and then enter in to RUN mode.



There are two methods to read different parameter Screens on the display.


- 1) Auto mode.
- 2) Manual mode.

Press Exit key for 6 Sec to select Automatic or Manual Mode

Type	Description
Auto Mode	In Auto mode, it allows you to monitor screens of different page at an interval of 5 seconds without any key press NOTE : By default the unit works in auto mode.
Manual Mode	In Manual mode, using the Enter key different parameter Screens can be viewed. The displayed Screen is seen until you manually change the Screen. It allows you to monitor screens of different page.

Note : By Default unit operates in automatic mode. In automatic mode online pages scroll automatically at the rate of 5 sec per page. In automatic mode if any key is pressed, unit temporarily switched to manual mode and the appropriate page is displayed.

Displays Total Reactive Energy.

Press the  key to save the set value and to come out of parameter setting after changing the set value.

1 <i>PASS</i>	Function: To set password.		
This parameter is used to set the password.			
	Min	Max	Fac.
	0	9998	11
2 <i>CHng PASS</i>	Function: To change the password.		
This parameter is used to change the password.			
	Min	Max	Fac.
	no	YES	no
3 <i>NE'' PASS</i>	Function: To set new password.		
This parameter is used to set the new password.			
	Min	Max	Fac.
	0	9998	0
4 <i>555</i>	Function: Network selection.		
Network selection ie, either 3 Phase 3 wire or 3 Phase 4 wire.			
	Min	Max	Fac.
	3P4	3P3	3P4
5 <i>CT-5</i>	Function: To select CT Secondary ratio.		
To select CT Secondary ratio.			
Fixed Value 5A.			
	Min	Max	Fac.
	5 A	10 kA	5 A
6 <i>CT-P</i>	Function: To select CT Primary ratio.		
To select CT Primary ratio.			
	Min	Max	Fac.
	5 A	10 kA	5 A
PT-5	Function: To select PT Secondary ratio.		
PT Secondary: To select PT Secondary ratio.			
	Min	Max	Fac.
	100V	500kV	350V
7 <i>PT-P</i>	Function: To select PT Primary ratio.		
PT Secondary: To select PT Primary ratio.			
	Min	Max	Fac.
	100V	500kV	350V
8 <i>r-Hr</i>	Function: Run Hours selection.		
To Select Run Hours.			
	Min	Max	Fac.
	0	10	0
9 <i>Id</i>	Function: To set device Id.		
To communicate properly controller side and PC side Id should match.			
	Min	Max	Fac.
	1	255	1
0 <i>BAUD</i>	Function: To set baud rate for communication.		
To communicate properly controller side and PC side baud rate should match.			
Range: 2400,4800,9600,19200.			
	Min	Max	Fac.
	2400	19200	9600
1 <i>PrL</i>	Function: Sets the parity check.		
To communicate properly controller side and PC side Parity should match.			
Range: none,Even,odd.			
	Min	Max	Fac.
	none	odd	none
2 <i>rSt Fct</i>	Function : To restore default settings of the controller.		
When set to YES all parameters are programmed to factory values.			
Useful to debug setting related problems.			
	Min	Max	Fac.
	no	YES	no
3 <i>rSt Enrg</i>	Function : To reset Energy.		
This parameter used to Reset Energy, Run Hour and MAX values.			
	Min	Max	Fac.
	no	YES	no
3.1 <i>ErSt PASS</i>	Function : To reset the Password.		
To reset energy, Run hour and MAX values user need to enter password.			
By entering correct password in this parameter user will be able to reset all energy parameter, Run Hour, MAX values.			
This password will be value greater than parameter mode password by 1.			
	Min	Max	Fac.
	0	9999	0
3.2 <i>rSt P-H</i>	Function : To reset Active Energy.		
If selected yes Active Energy will be Reset.			
	Min	Max	Fac.
	no	YES	no

13.3

rSt

UR-H

Function : To reset Apparent Energy.

If selected **yes** Apparent Energy will be Reset.

Min	Max	Fac.
no	YES	no

13.4

rSt

PURH

Function : To reset Reactive Energy.

If selected **yes** Reactive Energy will be Reset.

Min	Max	Fac.
no	YES	no

13.5

rSt

H-n

Function : To reset Run Hours.

If selected **yes** Run Hours will be Reset.

Min	Max	Fac.
no	YES	no

13.6

rSt

max

Function : To reset Max.




If selected YES reset MAX values.

Min	Max	Fac.
no	YES	no



Error Messages	
Message	Description
- - -	Power factor of corresponding phase shows this error message when input of corresponding is open.

Typical Wiring Diagram

NOTE : # All fuse types : 0.5A class CC UL type ; 0.5A fast acting 600V



Typical Wiring Diagram



Disclaimer: This manual & its contents remain the sole property of PVR CONTROLS . India and shall not be reproduced or distributed without authorization. Although great care has been taken in the preparation of this document, the company or its vendors in no event will be liable for direct, indirect, special, incidental or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages. No part of this manual may be reproduced or transmitted in any form or by any means without the prior written permission of the company.

PVR CONTROLS., reserves the right to make and changes or improvements without prior notice.

Warranty: This product is warranted against defects in materials and workmanship for a period of one year from the date of purchase. During the warranty period, product determined by us to be defective in form or function will be repaired or, at our option, replaced at no charge. This warranty does not apply if the product has been damaged by accident, abuse, and misuse or as a result of service or modification other than by the company. This warranty is in lieu of any other warranty expressed or implied. In no event shall the company be held liable for incidental or consequential damages, including lost revenue or lost business opportunity arising from the purchase of this product.

OUR OTHER PRODUCTS

sub-zero

Precision Control, *always*

• Digital Panel Meter

• Power Analyzer

• Timer

• PLC

• HMI

• Data Logger

REV0 - 07.06.2021_D&D