

Hose Elbow Coler Type (BSPT x Hose)

Code No.	Size		Std Packing
HEC 1818	1/8"	1/8"	50
HEC 1814	1/8"	1/4"	50
HEC18516	1/8"	5/16"	50
HEC 1838	1/8"	3/8"	50
HEC 1414	1/4"	1/4"	50
HEC 14516	1/4"	5/16"	50
HEC 1438	1/4"	3/8"	50
HEC 1412	1/4"	1/2"	25
HEC 3812	3/8"	1/2"	25
HEC 1238	1/2"	3/8"	25
HEC 1212	1/2"	1/2"	25
HEC 3434	3/4"	3/4"	10

"Y" joint Nipple

Code No.	Size Hose	Std Packing
YJN 14	1/4"	50
YJN 516	5/16"	50
YJN 38	3/8"	25
YJN 12	1/2"	25

Hose Elbow (BSPT x Hose)

Code No.	Size		Std Packing
HE 1818	1/8"	1/8"	50
HE 1814	1/8"	1/4"	50

HE 18516	1/8"	5/16"	50
HE 1838	1/8"	3/8"	50
HE 1414	1/4"	1/4"	50
HE 14516	1/4"	5/16"	50
HE 1438	1/4"	3/8"	50
HE 1412	1/4"	1/2"	25
HE 3814	3/8"	1/4"	50
HE 38516	3/8"	5/16"	50
HE 3838	3/8"	3/8"	50
HE 3812	3/8"	1/2"	25
HE 1238	1/2"	3/8"	25
HE 1212	1/2"	1/2"	25

Cross Joint Nipple

Code No.	Size Hose	Std. Packing
CJN 14	1/4"	25
CJN 516	5/16"	25
CJN 38	3/8"	25
CJN 12	1/2"	25

"T" Joint Nipple

Code No.	Size Hose	Std. Packing
TJN 316	3/16"	50
TJN 14	1/4"	50
TJN 516	5/16"	50
TJN 38	3/8"	50
TJN 12	1/2"	50
TJN 58	5/8"	50

TJN 34	3/4"	10
TJN 1	1"	10

Hose Nipple Male (BSP x Hose)

Code No.	Size		Std. Packing
	BSP	Hose	
HNM 1818	1/8"	1/8"	100
HNM 1814	1/8"	1/4"	100
HNM 18516	1/8"	5/16"	100
HNM 1838	1/8"	3/8"	100
HNM 1812	1/8"	1/2"	100
HNM 1418	1/4"	1/8"	100
HNM 1414	1/4"	1/4"	100
HNM 14516	1/4"	5/16"	100
HNM 1438	1/4"	3/8"	100
HNM 1412	1/4"	1/2"	50
HNM 3814	3/8"	1/4"	50
HNM 38516	3/8"	5/16"	50
HNM 3838	3/8"	3/8"	50
HNM 3812	3/8"	1/2"	50
HNM 1214	1/2"	1/4"	50
HNM 12516	1/2"	5/16"	50
HNM 1238	1/2"	3/8"	50
HNM 1212	1/2"	1/2"	50
HNM 1258	1/2"	5/8"	25
HNM 1234	1/2"	3/4"	25
HNM 3438	3/4"	3/8"	25
HNM 3412	3/4"	1/2"	25
HNM 3458	3/4"	5/8"	25
HNM 3434	3/4"	3/4"	25
HNM 341	3/4"	1"	10
HNM 138	1"	3/8"	10
HNM 112	1"	1/2"	10
HNM 158	1"	5/8"	10
HNM 134	1"	3/4"	20

HNM 1 1	1"	1"	20
HNM 114114	1 1/4"	1 1/4"	10
HNM 112112	1 1/2"	1 1/2"	10
HNM 2 2	2"	2"	10
HNM 212 212	2 1/2"	2 1/2"	10
HNM 3 3	3"	3"	10
HNM 4 4	4"	4"	10

Hose Nipple Female (Female x Hose)

Code No.	Size		Std. Packing
	BSP	Hose	
HNF 1818	1/8"	1/8"	50
HNF 1814	1/8"	1/4"	50
HNF 18516	1/8"	5/16"	50
HNF 1838	1/8"	3/8"	50
HNF 1418	1/4"	1/8"	50
HNF 1414	1/4"	1/4"	50
HNF 14516	1/4"	5/16"	50
HNF 1438	1/4"	3/8"	50
HNF 1412	1/4"	1/2"	50
HNF 3814	3/8"	1/4"	50
HNF 38516	3/8"	5/16"	50
HNF 3838	3/8"	3/8"	50
HNF 3812	3/8"	1/2"	25
HNF 1214	1/2"	1/4"	25
HNF 12516	1/2"	5/16"	25
HNF 1238	1/2"	3/8"	25
HNF 1212	1/2"	1/2"	25
HNF 3434	3/4"	3/4"	10
HNF 1 1	1"	1"	10

HNF 138	1"	3/8"	10
HNF 112	1"	1/2"	10
HNF 158	1"	5/8"	10