

Piezo Column



Column	Pneumatic
Type	Standard/Fanuc (Column transmit data (reading) to Fanuc controller O-i / Power Mate / 16 / 18 Series)
Input Channels	1
Air Cut-Off	Without Air Cut-Off / With Air Cut –Off Available (Air gets ON when Plug is placed in the Job else Air will remain OFF).
Resolution	0.1µm/ 0.5µm/ 1µm/ 5µm
Units	mm / Inch
Display	6 digit 7 segments
Setup	10
Measurement Modes	Cur, Max, Min, Diff
Modes	ID/OD
Indications	Reject, OK, Rework
Calibration	1point / 2 point Auto calibration
Scaling	Auto / Manual
PC Interface	RS-232, Wireless modules-optional
RS-232 Port	1/2 (In case of 2 port customer should specify both port requirement)
Data Transmission	Auto/Manual
Footswitch	Available
Output	3 open collector outputs provided on DB15
Pressure Sensor	Connector Available for connecting Pressure Sensor.