



YPL INSTRUMENTS PVT. LTD.

VIBRATING FORK LEVEL SWITCH:YPL-VFLS08

Introduction

The electronically stimulated fork vibrates at its mechanically Resonance frequency of 125 Hz when the fork is free of the service Material. The resonance is caused by the piezoelectric crystals. One of the Pezos crystals produces a small voltage which is transmitted to the Switching amplifier. If the fork is covered by the bulk material, a Damping effect is produced and the piezo crystal does not produce the Voltage and the amplifier will switch and a corresponding signal output is Actuated. The vibration of the fork has self-cleaning properties. The Light deposit on the container wall does not affect the Operation of the YPL FORK

Principle of Operation

Fast and Easy Installation No Calibration. No effect of Electrical properties of the Service material. High Reliability. Suitable for the highly dusty environment. Field selectable Operation logic. Can be configured either for High or Low Level point switching. Provides economical solutions. Various model not required. Reduces the Inventory cost.

PRIMARY AREA OF APPLICATION

Building industry materials, cement, sand, lime, etc
Foodstuff industry, milk powder, flour, salt, food grains, etc
Plastic industry, powder, granular etc. Timber industry,
Chemical and mining etc.

Specification

Process Connection	: 1 ½" BSP threaded standard / flanged(optional)
Enclosure	: aluminum
Length	: 200 mm standard/ Upto3000mm(as per application)
Micro Switch	: SPDT/DPDT
Max Temp.	: 200°C
Main voltage	:230/110 V AC (+/-15%), 50 Hz or 18-55 V DC 65 to 265 V AC (Optional)
Output	: a) 2 sets of potential free C/o contacts rated at 5 Amps, 230 V AC for non-inductive Loads. b) PNP/NPN with DC Mains
Cable entry	: 2nos. PG-16
Power consumption	: 2 VA



FIG.1



FIG.2

REGD. OFF: PLOT NO. 86-B, NEW DLF INDUSTRIAL AREA FARIDABAD-121003 (HARYANA)

Website: www.yplindia.in

Email Id: info.yplinstruments@gmail.com

Ph: [0129-3552448](tel:0129-3552448)