



# STEREO

## WPC LOUVERS

### EXTERIOR

#### Applications

- Façade
- Balcony Cladding
- Roof Cladding
- Gate Cladding
- Shutters
- Wall Decoration
- Ceiling Decoration
- Partition



# STEREO

## WPC LOUVERS

### EXTERIOR


#### WHY

- Economical
- Waterproof
- Termite Proof
- Fire Retardant
- Easy Installation
- Maintenance Free
- Long Life
- Durable and Strong
- Scratch Resistant





AFRICAN  
WALNUT



GOLDEN TIGER



GREY



TEAK


**STEREO  
WPC LOUVERS  
EXTERIOR**

CHALCOAL





4F



# STEREO


## WPC LOUVERS EXTERIOR

### SPECIFICATIONS

COMPOSITION	WOOD FIBRE + HDPE+ADDITIVES
THICKNESS	26 mm
WIDTH	219 mm (≈ 9 inches)
HEIGHT	2900 mm (9.5 feet)
PCS/BOX	4 PANNELS PER BOX
WEIGHT	9.5 Kg PER PANNEL (38 Kg PER BOX) for 2900 mm



5F



# STEREO


## WPC LOUVERS EXTERIOR

### SPECIFICATIONS

COMPOSITION	WOOD FIBRE + HDPE+ADDITIVES
THICKNESS	26 mm
WIDTH	219 mm (≈ 9 inches)
HEIGHT	2900 mm (9.5 feet)
PCS/BOX	4 PANNELS PER BOX
WEIGHT	9.5 Kg PER PANNEL (38 Kg PER BOX) for 2900 mm



2121F



# STEREO


## WPC LOUVERS EXTERIOR

### SPECIFICATIONS

COMPOSITION	WOOD FIBRE + HDPE+ADDITIVES
THICKNESS	26 mm
WIDTH	219 mm (≈ 9 inches)
HEIGHT	2900 mm (9.5 feet)
PCS/BOX	4 PANNELS PER BOX
WEIGHT	9.5 Kg PER PANNEL (38 Kg PER BOX) for 2900 mm



321F



# STEREO

## WPC LOUVERS EXTERIOR

### SPECIFICATIONS


COMPOSITION	WOOD FIBRE + HDPE+ADDITIVES
THICKNESS	26 mm
WIDTH	219 mm (≈ 9 inches)
HEIGHT	2900 mm (9.5 feet)
PCS/BOX	4 PANNELS PER BOX
WEIGHT	9.5 Kg PER PANNEL (38 Kg PER BOX) for 2900 mm



# STEREO

## WPC LOUVERS EXTERIOR

ALL MATCHING COLOURS TO  
COVER EDGES AND TOP



### SPECIFICATIONS

COMPOSITION	WOOD FIBRE + HDPE+ADDITIVES
THICKNESS	6 mm
WIDTH	50 X 50 mm (≈ 2 inches)
HEIGHT	2900 mm (9.5 feet)
PCS/BOX	20 PROFILE PER BOX
WEIGHT	1.85 Kg PER PROFILE (38 Kg PER BOX) for 2900 mm



# STEREO

## WPC LOUVERS

### EXTERIOR

## INSTALLATION


### STEP – 1

Install panel to the sub-frame with screws. Screws should be installed on tongue of the panels.



### STEP – 2

Place second panel adjacent to first panel with the concealing tongue hiding the screws.



### STEP – 3

Repeat the process until all needed panels are installed.

