



**Installation:**

**For fixing of lightweight objects like sockets, curtain rails etc. in plasterboards**


**1** Mount Jet-Drive® on screwdriver or bit (poz. 2). Press Jet-Drive® against the wall, where the fixture is wanted




**2** Screw Jet-Drive® flush with the wall. Avoid over-tightening



**3** Tighten the screw through the fixture and into the Jet-Drive®



**4** The installation is finished



| Type               | Dimensions        |                   |                  |                                | Fixing                | Load Capacities              |                            |
|--------------------|-------------------|-------------------|------------------|--------------------------------|-----------------------|------------------------------|----------------------------|
|                    | d                 | L <sub>bolt</sub> | L                | t <sub>fix</sub>               |                       | h                            | N <sub>rec</sub>           |
| Expandet Jet-Drive | Screw diameter mm | Screw length mm   | Anchor length mm | Thickness of fixture (Max.) mm | Thickness of board mm | Recommended tension load kN* | Recommended shear load kN* |
| Jet-Drive® Metal   | 4-4,5             |                   | 39               |                                | 9-26                  | 0,10 (0,14)                  | 0,18                       |
| Jet-Drive® Metal*  | 4,5               | 30                | 39               | 15                             | 9-26                  | 0,10 (0,14)                  | 0,18                       |
| Jet-Drive® Nylon*  | 4,5               | 30                | 32               | 10                             | 9-13                  | 0,10                         | 0,10                       |

\* Supplied with screw: 4,5 x 30 mm.  
 \* Loads are recommended maximum in plasterboards with 100 mm spacing. Numbers in ( ) are only valid for fixing in two layer plasterboard. Safety factor is included (≥ 3). 1 kN ≈ 100 kg.  
**Note:** Is the recommended spacing not applied the load capacity will be reduced.  
**Important:** See Expandet's "Principles for fastening" for general information on fastening as well as information on limited liability. (Can be downloaded at [www.expandet.com](http://www.expandet.com))

**Advantages:**

Fast and easy fixing of lightweight objects in plasterboards.  
 No pre-drilling.  
 Poz. 2 slot in both Jet-Drive® and screw.  
 Jet-Drive® Metal is fire resistant.

**Materials:**

Expandet Jet-Drive® Metal is supplied with or without screw (Poz. 2 slot).  
 Expandet Jet-Drive® Nylon is supplied with screw (Poz. 2 slot).  
 Withstands temperatures from -40°C to +80°C.  
 Expandet Jet-Drive® Metal: Alu-zinc.  
 Expandet Jet-Drive® Nylon: Glass fibre reinforced Nylon.  
 Screw: Zinc plated min. 5 µm.